CLI
Pages
Blog
Calendars
Tables
Analytics
SPACE SHORTCUTS
Here you can add shortcut links to the areas of Confluence content for your team or project. Configure shortcuts
PAGE TREE
Trunk
Trunk Handler
Phonegroup
Extensions
Trunk Groups
Route
Class of Service

Command Line Interface (CLI)

Created by Dmytro Bielinskyi, last modified by Jim Watson on Jan 26, 2018

The CLI is a powerful tool for viewing and editing your current system configuration.

To use the CLI, you will need to access your phone system's console via a supervisor. The system console is available either at the local terminal, or via SSH. We recommend the following SSH Clients:

- **Windows: PuTTY**
- **Mac: Terminal (or iTerm2), and ssh**
- **Linux: ssh or PuTTY**

Warning

With great power comes great responsibility.

Most changes done via the CLI are applied immediately.

Be familiar with all commands prior to using the CLI

Test the freeciub

Commands

Please note that all CLI commands are case sensitive.
There are two modes available to you when working in the CLI:

- Command

  Used for informational purposes, such as viewing current active call status or current device availability status.

  Used for controlling real-time aspects of the system, such as rebooting, disconnecting calls, or logging out call center agents

  This mode is the default mode when entering the CLI

- Configure

  Used for changing configurations for any settings, or viewing existing configurations for specific nodes.

  This mode can be accessed from the root of Command Mode by typing **configure**

Command Mode

- callqueue
  - **agent**

    Agent command description
  - **queues**

    Queues command description
- clear
  - voicemail
    - **box**
    - **greeting**
- configure
  - **terminal**
- disable
- exit
- ntr
  - **ip**
  - **ipv6**
- ping
  - **ip**
  - **ipv6**
  - **arp**
- reboot
- services
  - **restart**
  - **stop**
  - **start**
- show
  - callqueue
    - agent
      - **logins**

        Show currently logged in agents
      - **assignments**

        Show current agent assignments by call queue
    - queues
      - **status**

        Show current queue statuses
      - **config**

        Show current queue configurations
    - polycom
      - **status**

        Show current device status
      - **config**

        Show current device configuration
  - calls
    - **status**

      List all current active calls
  - cos

    List only CoS
    - **includes**

      List all CoS as well as any includes
  - devices
    - sip
      - **status**
    - sx
      - **status**
    - polycom
      - **status**
  - diag

    Show diagnostic information?
  - extensions
    - **status**
  - interfaces

    Show all interfaces and their current configuration/status
  - ip
    - **interface**
    - **route**
  - licenses

    Display current available and assigned licenses
  - phonegroups

    Display all current phonegroup information
  - polycoms

    Show only installed polycoms on the system
  - registrations
    - **sip**
    - **sx**
    - **all**
  - routes

    Show route information
  - running-config

    Show full configuration for all configured nodes
  - services

    Show running services
    - **detail**

      Show running services actual process details
  - startup-config

    Show startup-config (currently failing)
  - system-users

    Show system users, not sure what they relate to
  - tenants

    Show all current tenants on the active system
  - trunks

    Show all available trunks configured on the system
- traceroute

Configure Mode

- clone
  - daynight_group
  - extension
  - route
- core_settings
  - beep_on_nbr
  - enable_phone_reprogram_feature
  - enable_steal_holding_call
  - externhost
  - externip
  - externnethash
  - externtlsport
  - externtlsport
  - hosted_mode
  - localnet
  - pbx2_host
  - pbx2_port
  - pbx2_reg_period
  - pbx2_transport
  - pbx_ip
  - pbx_reg_period
  - pbx_transport
  - ringseconds_till_voicemail
  - server_name
  - sip_port
- core_sip_settings
  - dnsmode
  - qualify
  - qualifyfreq
  - rtpholdtimeout
  - rtptimeout
- cos

  Class of Service (CoS) takes a second argument which specifies either:
  - A new CoS name you wish to create and configure, e.g. "cos foo"
  - An existing CoS name you wish to make changes to, e.g. "cos foo" where "foo" is an already existing CoS

Like Be the first to like this
No labels
Write a comment...
{autoexpand}
EVALUATION LICENSE You are enjoying Confluence? Please consider purchasing it today.
Powered by Atlassian Confluence 6.6.7 Report a bug Atlassian News
ATLASSIAN