

Dialing Options

Direct Dial

1. To place a call enter the number you wish to dial. Alternatively, you can dial by pressing one of the favorited contacts from the Lines screen or by using the directory (Press Directory button > find contact > press Dial)
2. Press Dial.
3. Wait for the other party

Speakerphone Dial

1. Press the Speakerphone button.
2. Dial the number, press the Lines button to access your main contact, or press More followed by Directory to access the directory.
3. Press send if the number was manually entered, or press dial once you have found the contact you wish to dial if using the directory.

Headset Dial

1. Press Headset button.
2. Dial the number, press the Lines button to access your main contact, or press More followed by Directory to access the directory.
3. Press send if the number was manually entered, or press dial once you have found the contact you wish to dial if using the directory.
 1. If you press the headset button, it is important to remember that unless switch to a different method of placing/receiving calls future calls will be placed/answered through the headset

2. This feature is known as Headset Memory, and can be enabled/disabled from Home > Settings > Preferences > Headset > Headset Memory.

Handset Dial

1. Pickup Handset.
2. Dial the number, press the Lines button to access your favorited contacts, or press More followed by Directory to access the directory.
3. Press send if the number was manually entered, or press dial once you have found the contact you wish to dial, if using the directory.

Revision #3

Created 25 March 2024 15:00:48 by Robert Alexander

Updated 2 September 2024 18:54:32 by Andrew Baumes