

Trunk Handler

Defines a context that will handle incoming call routing.

Adding a Trunk Handler

1) Enter the CLI's configuration mode

2) Enter the name of the **Trunk Handler** you wish to create. You will be prompted with the minimum required settings.

```
vbox-markm(config)# trunk_handler chvoip
!! Notice: Editing new item: chvoip
!! Notice: Minimum requirements needed for insert:
!!  desc
vbox-markm(config-trunk_handler chvoip)# desc "Incoming Calls from Chicago"
vbox-markm(config-trunk_handler chvoip)#
```

3) Use the show command to ensure your settings are saved.

```
vbox-markm(config-trunk_handler chvoip)# show
! Generating running-config
!!

! ----- Trunk Handlers -----
trunk_handler chvoip
  desc "Incoming Calls from Chicago"
  exit

exit

vbox-markm(config-trunk_handler chvoip)#
```

Trunk Handler Settings

Description

You can also use the "?" **key** to view the description while in the CLI. * indicates a required setting.

Setting	Description
desc	(*) Non-functional description
do	To run exec commands in config mode
exit	Exit from this level (with notification if config was incomplete)
no	Clear settings
show	Show the running-config for the current item

Revision #2
Created 10 April 2024 16:32:50 by Robert Alexander
Updated 19 August 2024 19:36:20 by Andrew Baumes